Products

Scene Controller - DT21 - Key Fob

Broadcasts scene control messages to linked luminaires without the need for a mains connection.



Product Features

- A battery powered wireless Key Fob for scene control of lights enabling 5 scenes to be programmed and recalled.
- Communicates directly with luminaires.
- Where DALI DT8 control gear is used, colour temperature can also be controlled.
- Click and hold to dim up/down scenes.
- Can be used instead of, or as well as, Kellwood's wall mounted 6 button scene plate.

Specification

- 3v Lithium Battery.
- Model CR2032.
- 1-5 year battery life (dependent on usage).
- 868 MHz.
- 10mW ErP (Effective radiated Power).

Programming

When in programming mode the Key Fob can be detected using the commissioning tablet software and setup with up to 5 scenes.


To put the Key Fob in to programming mode:

1.Press Button 3.

2.Press Buttons 4 and 2 at the same time for 3 seconds.

Once the Key Fob is in programming mode it will remain in this mode until no buttons have been pressed and no messages have been sent to it by the tablet for 30 seconds. After this time the Key Fob will return to operating mode.

Dimensions



Part Code	Description
LC-LIP-FOB-BL-5X	Scene Set Key Fob with 5 Buttons.

www.kellwood.co.uk (+44) 01387 25 58 16 Catherinefield Industrial Estate, Dumfries, DG1 3PQ, Scotland, UK